

down Close HCI device.
reset Reset HCI device.
rstat Reset statistic counters.
auth Enable authentication (sets device to security mode 3).
noauth Disable authentication.
encrypt

Enable encryption (sets device to security mode 3).

noencrypt

Disable encryption.

secmgr Enable security manager (current kernel support is limited).

nosecmgr

Disable security manager.

piscan Enable page and inquiry scan.

noscan Disable page and inquiry scan.

iscan Enable inquiry scan, disable page scan.

pscan Enable page scan, disable inquiry scan.

ptype [type]

With no type, displays the current packet types. Otherwise, all the packet types specified by type are set. type is a comma-separated list of packet types, where the possible packet types are DM1, DM3, DM5, DH1, DH3, DH5, HV1, HV2, HV3.

name [name]

With no name, prints local name. Otherwise, sets local name to name.

class [class]

With no class, prints class of device. Otherwise, sets class of device to class. class is a 24-bit hex number describing the class of device, as specified in section 1.2 of the Bluetooth Assigned Numbers document.

voice [voice]

With no voice, prints voice setting. Otherwise, sets voice setting to voice. voice is a 16-bit hex number describing the voice setting.

iac [iac]

With no iac, prints the current IAC setting. Otherwise, sets the IAC to iac.

inqtpl [level]

With no level, prints out the current inquiry transmit power level. Otherwise,

sets inquiry transmit power level to level.

inqmode [mode]

With no mode, prints out the current inquiry mode. Otherwise, sets inquiry mode to mode.

??

?mode ? Description ?

??

?0 ? Standard Inquiry ?

??

?1 ? Inquiry with RSSI ?

??

?2 ? Inquiry with RSSI or Extended ?

? ? Inquiry ?

??

inqdata [data]

With no data, prints out the current inquiry data. Otherwise, sets inquiry data to data.

inqtype [type]

With no type, prints out the current inquiry scan type. Otherwise, sets inquiry scan type to type.

inqparams [win:int]

With no win:int, prints inquiry scan window and interval. Otherwise, sets inquiry scan window to win slots and inquiry scan interval to int slots.

pageparms [win:int]

With no win:int, prints page scan window and interval. Otherwise, sets page scan window to win slots and page scan interval to int slots.

pageto [to]

With no to, prints page timeout. Otherwise, sets page timeout to to slots.

afhmode [mode]

With no mode, prints out the current AFH mode. Otherwise, sets AFH mode to mode.

????????????????????????

?mode ? Description ?

????????????????????????

```
?0  ? Enable  ?  
?????????????????????????  
?1  ? Disable  ?  
?????????????????????????
```

sspmode [mode]

With no mode, prints out the current Simple Pairing mode. Otherwise, sets Simple Pairing mode to mode.

```
?????????????????????????  
?mode ? Description ?  
?????????????????????????  
?0  ? Enable  ?  
?????????????????????????  
?1  ? Disable  ?  
?????????????????????????
```

aclmtu mtu:pkt

Sets ACL MTU to mtu bytes and ACL buffer size to pkt packets.

scomtu mtu:pkt

Sets SCO MTU to mtu bytes and SCO buffer size to pkt packets.

delkey <bdaddr>

This command deletes the stored link key for bdaddr from the device.

oobdata

Get local OOB data (invalidates previously read data).

commands

Display supported commands.

features

Display device features.

version

Display version information.

revision

Display revision information.

lm [mode]

With no mode, prints link mode. CENTRAL or PERIPHERAL mean, respectively, to ask to become central or to remain peripheral when a connection request comes in. The ad?

ditional keyword ACCEPT means that baseband connections will be accepted even if there are no listening AF_BLUETOOTH sockets. mode is NONE or a comma-separated list of keywords, where possible keywords are CENTRAL and ACCEPT. NONE sets link policy to the default behaviour of remaining peripheral and not accepting baseband connections when there are no listening AF_BLUETOOTH sockets. If CENTRAL is present, the device will ask to become central if a connection request comes in. If ACCEPT is present, the device will accept baseband connections even when there are no listening AF_BLUETOOTH sockets.

block <bdaddr>

Add a device to the reject list

unblock <bdaddr>

Remove a device from the reject list

lerandaddr <bdaddr>

Set LE Random Address

leadv [type]

Enable LE Advertising.

```
?????????????????????????????????????????????  
?type ? Description ?  
?????????????????????????????????????????????  
?0 ? Connectable undirected advertis? ?  
? ? ing (default) ?  
?????????????????????????????????????????????  
?3 ? Non connectable undirected ad? ?  
? ? vertising ?  
?????????????????????????????????????????????
```

noleadv

Disable LE Advertising

lestates

Display the supported LE states

RESOURCES

<http://www.bluez.org>

REPORTING BUGS

linux-bluetooth@vger.kernel.org

AUTHOR

Maxim Krasnyansky <maxk@qualcomm.com>, Marcel Holtmann <marcel@holtmann.org>, Fabrizio Gennari <fabrizio.gennari@philips.com>

COPYRIGHT

Free use of this software is granted under the terms of the GNU Lesser General Public License (LGPL).

BlueZ

Nov 11, 2002

HCICONFIG(1)