



## ***Rocky Enterprise Linux 9.2 Manual Pages on command 'Xtigervnc.1'***

**C:\>man Xtigervnc.1**

Xtigervnc(1)                    Virtual Network Computing                    Xtigervnc(1)

### NAME

Xtigervnc - the X VNC server

### SYNOPSIS

Xtigervnc [options] :display#

### DESCRIPTION

Xtigervnc is the X VNC (Virtual Network Computing) server. It is based on a standard X server, but it has a "virtual" screen rather than a physical one. X applications display themselves on it as if it were a normal X display, but they can only be accessed via a VNC viewer - see `vncviewer(1)`.

So Xtigervnc is really two servers in one. To the applications it is an X server, and to the remote VNC users it is a VNC server. By convention we have arranged that the VNC server display number will be the same as the X server display number, which means you can use eg. `snoopy:2` to refer to display 2 on machine "snoopy" in both the X world and the VNC world.

The best way of starting Xvnc is via the `vncserver` script. This sets up the environment appropriately and runs some X applications to get you going. See the manual page for `vncserver(1)` for more information.

### OPTIONS

Xtigervnc takes lots of options - running `Xvnc -help` gives a list. Many of these are standard X server options, which are described in the `Xserver(1)` manual page.

In addition to options which can only be set via the command-line, there are also

"parameters" which can be set both via the command-line and through the vnc? config(1) program.

-geometry widthxheight

Specify the size of the desktop to be created. Default is 1024x768.

-depth depth

Specify the pixel depth in bits of the desktop to be created. Default is 24, other possible values are 8, 15, and 16 - anything else is likely to cause strange behaviour by applications.

-pixelformat format

Specify pixel format for server to use (BGRnnn or RGBnnn). The default for depth 8 is BGR233 (meaning the most significant two bits represent blue, the next three green, and the least significant three represent red), the default for depth 16 is RGB565 and for depth 24 is RGB888.

-interface IP address

Listen on interface. By default Xtigervnc listens on all available interfaces.

-inetd This significantly changes Xtigervnc's behaviour so that it can be launched from inetd. See the section below on usage with inetd.

-help List all the options and parameters

## PARAMETERS

VNC parameters can be set both via the command-line and through the vncconfig(1) program, and with a VNC-enabled Xorg server via Options entries in the xorg.conf file.

Parameters can be turned on with -param or off with -param=0. Parameters which take a value can be specified as -param value. Other valid forms are param=value -param=value --param=value. Parameter names are case-insensitive.

-desktop desktop-name

Each desktop has a name which may be displayed by the viewer. It defaults to "x11".

-rfbport port

Specifies the TCP port on which Xtigervnc listens for connections from viewers (the protocol used in VNC is called RFB - "remote framebuffer"). The default is 5900 plus the display number.

**-UseIPv4**

Use IPv4 for incoming and outgoing connections. Default is on.

**-UseIPv6**

Use IPv6 for incoming and outgoing connections. Default is on.

**-rfbunixpath path**

Specifies the path of a Unix domain socket on which Xtigervnc listens for connections from viewers, instead of listening on a TCP port.

**-rfbunixmode mode**

Specifies the mode of the Unix domain socket. The default is 0600.

**-rfbwait time, -ClientWaitTimeMillis time**

Time in milliseconds to wait for a viewer which is blocking the server. This is necessary because the server is single-threaded and sometimes blocks until the viewer has finished sending or receiving a message - note that this does not mean an update will be aborted after this time. Default is 20000 (20 seconds).

**-rfbauth passwd-file, -PasswordFile passwd-file**

Password file for VNC authentication. There is no default, you should specify the password file explicitly. Password file should be created with the vncpasswd(1) utility. The file is accessed each time a connection comes in, so it can be changed on the fly.

**-AcceptCutText**

Accept clipboard updates from clients. Default is on.

**-MaxCutText bytes**

The maximum size of a clipboard update that will be accepted from a client. Default is 262144.

**-SendCutText**

Send clipboard changes to clients. Default is on.

**-SendPrimary**

Send the primary selection and cut buffer to the server as well as the clipboard selection. Default is on.

**-AcceptPointerEvents**

Accept pointer press and release events from clients. Default is on.

**-AcceptKeyEvents**

Accept key press and release events from clients. Default is on.

**-AcceptSetDesktopSize**

Accept requests to resize the size of the desktop. Default is on.

**-DisconnectClients**

Disconnect existing clients if an incoming connection is non-shared. Default is on. If DisconnectClients is false, then a new non-shared connection will be refused while there is a client active. When combined with NeverShared this means only one client is allowed at a time.

**-NeverShared**

Never treat incoming connections as shared, regardless of the client-specified setting. Default is off.

**-AlwaysShared**

Always treat incoming connections as shared, regardless of the client-specified setting. Default is off.

**-Protocol3.3**

Always use protocol version 3.3 for backwards compatibility with badly-behaved clients. Default is off.

**-FrameRate fps**

The maximum number of updates per second sent to each client. If the screen updates any faster than those changes will be aggregated and sent in a single update to the client. Note that this only controls the maximum rate and a client may get a lower rate when resources are limited. Default is 60.

**-CompareFB mode**

Perform pixel comparison on framebuffer to reduce unnecessary updates. Can be either 0 (off), 1 (always) or 2 (auto). Default is 2.

**-ZlibLevel level**

Zlib compression level for ZRLE encoding (it does not affect Tight encoding). Acceptable values are between 0 and 9. Default is to use the standard compression level provided by the zlib(3) compression library.

**-ImprovedHextile**

Use improved compression algorithm for Hextile encoding which achieves better compression ratios by the cost of using slightly more CPU time. Default is on.

-SecurityTypes sec-types

Specify which security scheme to use for incoming connections. Valid values are a comma separated list of None, VncAuth, Plain, TLSNone, TLSVnc, TLSPlain, X509None, X509Vnc and X509Plain. Default is VncAuth,TLSVnc.

-Password password

Obfuscated binary encoding of the password which clients must supply to access the server. Using this parameter is insecure, use PasswordFile parameter instead.

-PlainUsers user-list

A comma separated list of user names that are allowed to authenticate via any of the "Plain" security types (Plain, TLSPlain, etc.). Specify \* to allow any user to authenticate using this security type. Default is to deny all users.

-pam\_service name, -PAMService name

PAM service name to use when authentication users using any of the "Plain" security types. Default is vnc.

-X509Cert path

Path to a X509 certificate in PEM format to be used for all X509 based security types (X509None, X509Vnc, etc.).

-X509Key path

Private key counter part to the certificate given in X509Cert. Must also be in PEM format.

-GnuTLSPriority priority

GnuTLS priority string that controls the TLS session's handshake algorithms. See the GnuTLS manual for possible values. Default is NORMAL.

-UseBlacklist

Temporarily reject connections from a host if it repeatedly fails to authenticate. Default is on.

-BlacklistThreshold count

The number of unauthenticated connection attempts allowed from any individual host before that host is black-listed. Default is 5.

-BlacklistTimeout seconds

The initial timeout applied when a host is first black-listed. The host

cannot re-attempt a connection until the timeout expires. Default is 10.

**-IdleTimeout seconds**

The number of seconds after which an idle VNC connection will be dropped.

Default is 0, which means that idle connections will never be dropped.

**-MaxDisconnectionTime seconds**

Terminate when no client has been connected for N seconds. Default is 0.

**-MaxConnectionTime seconds**

Terminate when a client has been connected for N seconds. Default is 0.

**-MaxIdleTime seconds**

Terminate after N seconds of user inactivity. Default is 0.

**-QueryConnect**

Prompts the user of the desktop to explicitly accept or reject incoming connections. Default is off.

The `vnconfig(1)` program must be running on the desktop in order for QueryConnect to be supported.

**-QueryConnectTimeout seconds**

Number of seconds to show the Accept Connection dialog before rejecting the connection. Default is 10.

**-localhost**

Only allow connections from the same machine. Useful if you use SSH and want to stop non-SSH connections from any other hosts.

**-Log logname:dest:level**

Configures the debug log settings. `dest` can currently be `stderr`, `stdout` or `syslog`, and `level` is between 0 and 100, 100 meaning most verbose output.

`logname` is usually `*` meaning all, but you can target a specific source file if you know the name of its "LogWriter". Default is `*:stderr:30`.

**-RemapKeys mapping**

Sets up a keyboard mapping. `mapping` is a comma-separated string of character mappings, each of the form `char->char`, or `char<>char`, where `char` is a hexadecimal keysym. For example, to exchange the `"` and `@` symbols you would specify the following:

```
RemapKeys=0x22<>0x40
```

**-AvoidShiftNumLock**

Key affected by NumLock often require a fake Shift to be inserted in order for the correct symbol to be generated. Turning on this option avoids these extra fake Shift events but may result in a slightly different symbol (e.g. a Return instead of a keypad Enter).

#### -RawKeyboard

Send keyboard events straight through and avoid mapping them to the current keyboard layout. This effectively makes the keyboard behave according to the layout configured on the server instead of the layout configured on the client. Default is off.

#### -AllowOverride

Comma separated list of parameters that can be modified using VNC extension. Parameters can be modified for example using `vnconfig(1)` program from inside a running session.

Allowing override of parameters such as `PAMService` or `PasswordFile` can negatively impact security if `Xtigervnc` runs under different user than the programs allowed to override the parameters.

When `NoClipboard` parameter is set, allowing override of `SendCutText` and `AcceptCutText` has no effect.

Default is `desktop,AcceptPointerEvents,SendCutText,AcceptCutText,SendPrimary,SetPrimary`.

## USAGE WITH INETD

By configuring the `inetd(1)` service appropriately, `Xtigervnc` can be launched on demand when a connection comes in, rather than having to be started manually. When given the `-inetd` option, instead of listening for TCP connections on a given port it uses its standard input and standard output. There are two modes controlled by the `wait/nowait` entry in the `inetd.conf` file.

In the `nowait` mode, `Xtigervnc` uses its standard input and output directly as the connection to a viewer. It never has a listening socket, so cannot accept further connections from viewers (it can however connect out to listening viewers by use of the `tigervncconfig` program). Further viewer connections to the same TCP port result in `inetd` spawning off a new `Xtigervnc` to deal with each connection. When the connection to the viewer dies, the `Xtigervnc` and any associated X clients die.

This behaviour is most useful when combined with the XDMCP options `-query` and

-once. An typical example in inetd.conf might be (all on one line):

```
5950 stream tcp nowait nobody /usr/local/bin/Xtigervnc Xtigervnc -inetd -query  
localhost -once securitytypes=none
```

In this example a viewer connection to :50 will result in a new Xtigervnc for that connection which should display the standard XDM login screen on that machine. Because the user needs to login via XDM, it is usually OK to accept connections without a VNC password in this case.

In the wait mode, when the first connection comes in, inetd gives the listening socket to Xtigervnc. This means that for a given TCP port, there is only ever one Xtigervnc at a time. Further viewer connections to the same port are accepted by the same Xtigervnc in the normal way. Even when the original connection is broken, the Xtigervnc will continue to run. If this is used with the XDMCP options -query and -once, the Xtigervnc and associated X clients will die when the user logs out of the X session in the normal way. It is important to use a VNC password in this case. A typical entry in inetd.conf might be:

```
5951 stream tcp wait james /usr/local/bin/Xtigervnc Xtigervnc -inetd  
-query localhost -once passwordFile=/home/james/.vnc/passwd
```

In fact typically, you would have one entry for each user who uses VNC regularly, each of whom has their own dedicated TCP port which they use. In this example, when user "james" connects to :51, he enters his VNC password, then gets the XDM login screen where he logs in in the normal way. However, unlike the previous example, if he disconnects, the session remains persistent, and when he reconnects he will get the same session back again. When he logs out of the X session, the Xtigervnc will die, but of course a new one will be created automatically the next time he connects.

#### SEE ALSO

tigervncconfig(1), tigervncpasswd(1), tigervncserver(1), xtigervncviewer(1),  
Xserver(1), inetd(1)  
<https://www.tigervnc.org>

#### AUTHOR

Tristan Richardson, RealVNC Ltd. and others.

VNC was originally developed by the RealVNC team while at Olivetti Research Ltd / AT&T Laboratories Cambridge. TightVNC additions were implemented by Constantin

Kaplinsky. Many other people have since participated in development, testing and support. This manual is part of the TigerVNC software suite.

TigerVNC

Xtigervnc(1)