



Rocky Enterprise Linux 9.2 Manual Pages on command 'sg_reset.8'

C:~>man sg_reset.8

SG_RESET(8) SG3_UTILS SG_RESET(8)

NAME

sg_reset - sends SCSI device, target, bus or host reset; or checks reset state

SYNOPSIS

```
sg_reset [--bus] [--device] [--help] [--host] [--no-esc] [--target] [--verbose]
[--version] DEVICE
```

DESCRIPTION

The sg_reset utility with no options (just a DEVICE) reports on the reset state (e.g. if a reset is underway) of the DEVICE. When given a --device, --target, --bus or --host option it requests a device, target, bus or host reset respectively.

A device reset is applied to the Logical Unit (LU) corresponding to DEVICE. It is most likely implemented by a Low level Driver (LLD) in Linux as a LOGICAL UNIT RESET task management function.

The ability to reset a SCSI target was added in Linux kernel 2.6.27 . A LLD may send Low level Drivers (LLDs) the I_T NEXUS RESET task management function. Alternatively it may use a transport mechanism to do the same thing (e.g. a hard reset on the link containing a SAS target).

In the Linux kernel 2.6 and 3 series this utility can be called on sd, sr (cd/dvd), st or sg device nodes; if the user has appropriate permissions.

Users of this utility can check whether a reset recovery is already underway before trying to send a new reset with this utility. Calling this utility with no options, just the DEVICE, will do such a check.

OPTIONS

`-b, --bus`

attempt a SCSI bus reset. A bus reset is a SCSI Parallel Interface (SPI) concept not found in modern transports. A recent LLD may implement it as a series of resets on targets that might be considered as siblings to the target on the DEVICE path.

`-d, --device`

attempt a SCSI device reset. This would typically involve sending a LOGICAL UNIT RESET task management function to DEVICE.

`-z, --help`

print the usage message then exit.

`-H, --host`

attempt a host reset. The "host" in this context is often called a Host Bus Adapter (HBA) and contains one or more SCSI initiators.

`-N, --no-esc`

without this option, if a device reset (`--device`) fails then it will escalate to a target reset. And if a target reset (`--target`) fails then it will escalate to a bus reset. And if a bus reset (`--bus`) fails then it will escalate to a host reset. With this option only the requested reset is attempted. An alternate option name of `--no-escalate` is also accepted.

`--no-escalate`

The same as `-N, --no-esc`.

`-t, --target`

attempt a SCSI target reset. A SCSI target contains one or more LUs. This would typically involve sending a I_T NEXUS RESET task management function to DEVICE. There may be a transport action that is equivalent (e.g. in SAS a hard reset on the link that contains the target).

`-v, --verbose`

increase the degree of verbosity (debug messages).

`-V, --version`

prints the version string then exits.

NOTES

The error recovery code within the Linux kernel (SCSI mid-level) when faced with a

SCSI command timing out and no response from the device (LU) does the following.

First it tries a device reset and if that is not successful tries a target reset.

If that is not successful it tries a bus reset. If that is not successful it tries

a host reset. The "device,target,bus,host" order is the reset escalation that the

--no-esc option attempts to stop. In large storage configurations the escalation

may be (very) undesirable.

This utility calls the SG SCSI RESET ioctl and as of lk 3.10.7 the --no-esc option

is not supported. Patches to implement this functionality may be accepted in lk

3.18 or 3.19 .

SAM-4 and 5 define a hard reset, a LOGICAL UNIT RESET and a I_T NEXUS RESET. A hard

reset is defined to be a power on condition, a microcode change or a transport re?

set event. LOGICAL UNIT RESET and I_T NEXUS RESET can be requested via task manage?

ment functions (and support for LOGICAL UNIT RESET is mandatory). In Linux the SCSI

subsystem leaves it up to the LLDs as to exactly what type (if any) of reset is

performed. The "bus reset" is SCSI Parallel Interface (SPI) concept that may not

map well to recent SCSI transports so it may be a dummy operation. A "host reset"

attempts to re-initialize the HBA that the request passes through en route to the

DEVICE. Note that a "host reset" and a "bus reset" may cause collateral damage.

This utility does not allow individual SCSI commands to be aborted. SAM-4 defines

ABORT TASK and ABORT TASK SET task management functions for that.

Prior to SAM-3 there was a TARGET RESET task management function. And in SAM-4 I_T

NEXUS RESET appeared which seems closely related: the "I_T" stands for Initia?

tor-Target.

Transports may have their own types of resets not supported by this utility. For

example SAS has a link reset in which both ends of a physical link (e.g. between a

SAS expander and a SAS tape drive) renegotiate their connection.

Prior to version 0.57 of this utility the command line had short options only (e.g.

-d but not --device). Also -h invoked a host reset while in the current version -h

is equivalent to --help and both -H and --host invoke a host reset. For backward

compatibility define the environment variable SG3_UTILS_OLD_OPTS or SG_RE?

SET_OLD_OPTS . In this case -h will invoke a host reset and the output will be ver?

bose as it was previously (equivalent to using the --verbose option now). For ex?

ample:

```
SG_RESET_OLD_OPTS=1 sg_reset -h /dev/sg1
```

sg_reset: starting host reset

sg_reset: completed host reset

ENVIRONMENT VARIABLES

Since sg3_utils version 1.23 the environment variables SG3_UTILS_OLD_OPTS or SG_RESET_OLD_OPTS can be given. When either is present this utility will expect the older command line options as outlined in the NOTES section.

AUTHORS

Written by Douglas Gilbert.

COPYRIGHT

Copyright ? 1999-2017 Douglas Gilbert

This software is distributed under the GPL version 2. There is NO warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

sg3_utils-1.43

October 2017

SG_RESET(8)