



Linux Ubuntu 26.04 Manual Pages on command 'mbimcli.1'

\$ man mbimcli.1

MBIMCLI(1) User Commands MBIMCLI(1)

NAME

mbimcli - Control MBIM devices

DESCRIPTION

Usage:

mbimcli [OPTION???] - Control MBIM devices

Help Options:

-h, --help

Show help options

--help-all

Show all help options

--help-basic-connect

Show Basic Connect Service options

--help-phonebook

Show Phonebook Service options

--help-dss

Show Device Service Stream options

--help-ms-firmware-id

Show Microsoft Firmware ID Service options

--help-ms-host-shutdown

Show Microsoft Host Shutdown Service options

--help-ms-sar

Show Microsoft SAR Service options

--help-atds

Show AT&T Device Service options

--help-intel-firmware-update

Show Intel Firmware Update Service options

--help-ms-basic-connect-extensions

Show Microsoft Basic Connect Extensions Service options

--help-quectel

Show Quectel Service options

--help-link-management

Show link management specific options

--help-intel-thermal-rf

Show Intel Thermal RF Service options

--help-ms-voice-extensions

Show Microsoft Voice Extensions Service options

--help-ms-uicc-low-level-access

Show Microsoft UICC Low Level Access Service options

--help-intel-mutual-authentication

Show Intel mutual authentication Service options

--help-intel-tools

Show Intel 5G tools options

--help-google

Show Google Service options

--help-fibocom

Show Fibocom Service options

--help-sms

Show SMS service options

--help-compal

Show Compal Service options

--help-intel-at-tunnel

Show Intel AT Tunnel Service options

Basic Connect options:

--query-device-caps

Query device capabilities

--query-subscriber-ready-status

Query subscriber ready status

--query-radio-state

Query radio state

--set-radio-state=[(on|off)]

Set radio state

--query-device-services

Query device services

--query-pin-state

Query PIN state

--enter-pin=[(PIN type),(current PIN)]

Enter PIN (PIN type is optional, defaults to PIN1, allowed options: (pin1,net?

work-pin,network-subset-pin,service-provider-pin,corporate-pin)

--change-pin=[(current PIN),(new PIN)]

Change PIN

--enable-pin=[(current PIN)]

Enable PIN

--disable-pin=[(PIN type),(current PIN)]

Disable PIN (PIN type is optional, see enter-pin for details)

--enter-puk=[(PUK type),(PUK),(new PIN)]

Enter PUK (PUK type is optional, defaults to PUK1, allowed options: (puk1,net?

work-puk,network-subset-puk,service-provider-puk,corporate-puk)

--query-pin-list

Query PIN list

--query-home-provider

Query home provider

--query-preferred-providers

Query preferred providers

--query-visible-providers

Query visible providers

--query-register-state

Query register state

--set-register-state=["key=value,..."]

Set basic register settings (allowed keys: action, provider-id, data-class)

--query-signal-state

Query signal state

--query-packet-service-state

Query packet service state

--attach-packet-service

Attach to the packet service

--detach-packet-service

Detach from the packet service

--query-connection-state=[SessionID]

Query connection state (SessionID is optional, defaults to 0)

--connect=["key=value,..."]

Connect (allowed keys: session-id, access-string, ip-type, auth, username, password, compression, context-type)

--query-ip-configuration=[SessionID]

Query IP configuration (SessionID is optional, defaults to 0)

--disconnect=[SessionID]

Disconnect (SessionID is optional, defaults to 0)

--query-packet-statistics

Query packet statistics

--query-ip-packet-filters=[SessionID]

Query IP packet filters (SessionID is optional, defaults to 0)

--set-ip-packet-filters=["key=value,..."]

Set IP packet filters (allowed keys: session-id, packet-filter, packet-mask, filter-id)

--query-provisioned-contexts

Query provisioned contexts

--set-provisioned-contexts=["key=value,..."]

Set provisioned contexts (allowed keys: context-id, context-type, auth, compression, username, password, access-string, provider-id)

--set-signal-state=["key=value,..."]

Set signal state (allowed keys: signal-strength-interval, rssi-threshold, error-rate-threshold)

--set-network-idle-hint=[(enabled|disabled)]

Set network idle hint

--query-network-idle-hint

Query network idle hint

--set-emergency-mode=[(on|off)]

Set emergency mode

--query-emergency-mode

Query emergency mode

--set-service-activation=[Data]

Set service activation

Phonebook options:

--phonebook-query-configuration

Query the phonebook configuration

--phonebook-read=[(Phonebook index)]

Read phonebook entry with given index

--phonebook-read-all

Read all phonebook entries

--phonebook-write=[(Name),(Number)[,(Index)]]

Add new phonebook entry or update an existing one

--phonebook-delete=[(Phonebook index)]

Delete phonebook entry with given index

--phonebook-delete-all

Delete all phonebook entries

Device Service Stream options:

--dss-connect=[(UUID),(Session ID)]

Connect DSS session

--dss-disconnect=[(UUID),(Session ID)]

Disconnect DSS session

Microsoft Firmware ID options:

--ms-query-firmware-id

Query firmware ID

Microsoft Host Shutdown options:

--ms-notify-host-shutdown

Notify that host is shutting down

Microsoft SAR options:

--ms-set-sar-config=[(device|os),(enabled|disabled)[,{antenna_index,backoff_index}...]]

Set SAR config

--ms-query-sar-config

Query SAR config

--ms-set-transmission-status=[(enabled|disabled),(timer)]

Set transmission status and hysteresis timer (in seconds)

--ms-query-transmission-status

Query transmission status

AT&T Device Service options:

--atds-query-signal

Query signal info

--atds-query-location

Query cell location

Intel Firmware Update Service options:

--intel-modem-reboot=[(Boot Mode),(Timeout)]

Reboot modem. Boot mode and timeout arguments only required if MBIMEx >= 2.0.

Microsoft Basic Connect Extensions options:

--ms-query-pco=[SessionID]

Query PCO value (SessionID is optional, defaults to 0)

--ms-query-lte-attach-configuration

Query LTE attach configuration

--ms-set-lte-attach-configuration=[(default|restore-fac?

tory)[,"key=value,..."[/"key=value,..."[/"key=value,..."]]]

Set LTE attach configurations (groups separated by '/' if more than one, with al?

lowed-keys: ip-type, roaming-control, source, access-string, username, password, com?

pression, auth)

--ms-query-lte-attach-info

Query LTE attach status information

--ms-query-sys-caps

Query system capabilities

--ms-query-device-caps

Query device capabilities

--ms-query-slot-info-status=[SlotIndex]

Query slot information status

--ms-set-device-slot-mappings=[(SlotIndex)[,(SlotIndex)[,...]]]

Set device slot mappings for each executor

--ms-query-device-slot-mappings

Query device slot mappings

--ms-query-location-info-status

Query location info status

--ms-set-provisioned-contexts=["key=value,..."]

Set provisioned contexts (allowed keys: operation, context-type, ip-type, state, roaming-control, media-type, source, auth, compression, username, password, access-string)

--ms-query-provisioned-contexts

Query provisioned contexts

--ms-query-base-stations-info

Query base stations info

--ms-device-reset

Reset device

--ms-query-version=[(MBIM version),(MBIM extended version)]

Exchange supported version information. Since MBIMEx v2.0.

--ms-query-registration-parameters

Query registration parameters. Since MBIMEx v3.0.

--ms-set-registration-parameters=["key=value,..."]

Set registration parameters (required keys: mico-mode, drx-cycle, ldn-info, default-pdu-activation-hint, re-register-if-needed). Since MBIMEx v3.0.

--ms-query-modem-configuration

Query modem configuration. Since MBIMEx v3.0.

--ms-query-wake-reason

Query wake reason. Since MBIMEx v3.0.

Quectel options:

--quectel-query-radio-state

Query radio state

--quectel-set-radio-state=[(on)]

Set radio state

--quectel-set-command=[(Command type),("Command")]

Send command to module (Command type is optional, defaults to AT, allowed options:

(at, system)

Link management options:

--link-list=[IFACE]

List links created from a given interface

--link-add=[iface=IFACE,prefix=PREFIX[,session-id=N]]

Create new network interface link

--link-delete=IFACE

Delete a given network interface link

--link-delete-all=[IFACE]

Delete all network interface links from the given interface

Intel Thermal RF Service options:

--intel-query-rfim

Query RFIM frequency information

--intel-set-rfim=[(on|off)]

Enable or disable RFIM (disabled by default)

Microsoft Voice Extensions Service options:

--ms-query-nitz

Query network identity and time zone

Microsoft UICC Low Level Access Service options:

--ms-query-uicc-application-list

Query UICC application list

--ms-query-uicc-file-status=["key=value,..."]

Query UICC file status (allowed keys: application-id, file-path)

--ms-query-uicc-read-binary=["key=value,..."]

Read UICC binary file (allowed keys: application-id, file-path, read-offset, read-size, local-pin and data)

--ms-query-uicc-read-record=["key=value,..."]

Read UICC record file (allowed keys: application-id, file-path, record-number, local-pin and data)

--ms-set-uicc-open-channel=["key=value,..."]

Set UICC open channel (allowed keys: application-id, selectp2arg, channel-group)

--ms-set-uicc-close-channel=["key=value,..."]

Set UICC close channel (allowed keys: channel, channel-group)

--ms-query-uicc-atr

Query UICC atr

--ms-set-uicc-apdu=["key=value,..."]

Set UICC apdu (allowed keys: channel, secure-message, classbyte-type, command)

--ms-set-uicc-reset=[(Pass Through Action)]

Set UICC reset

--ms-query-uicc-reset

Query UICC reset

--ms-set-uicc-terminal-capability=["key=value,..."]

Set UICC terminal capability (allowed keys: terminal-capability)

--ms-query-uicc-terminal-capability

Query UICC terminal capability

Intel mutual authentication Service options:

--intel-query-fcc-lock

Query FCC lock information

--intel-set-fcc-lock=[(ResponsePresent),(Response)]

Set FCC lock information

Intel 5G tools options

--intel-set-trace-config=[(TraceCmd)|(TraceValue)]

Set trace configuration

--intel-query-trace-config=[(TraceCmd)]

Query trace configuration

Google options:

--google-set-carrier-lock=[(Data)]

Set Google Carrier Lock

--google-query-carrier-lock

Query Google Carrier Lock

Fibocom options:

--fibocom-set-at-command="<AT command>"

send AT command to modem, and receive AT response

Simple message service options:

--sms-delete=[(all|new|old|sent|draft|index=N)]

Delete all SMS matching a given filter

--sms-read=[(all|new|old|sent|draft|index=N)]

Read all SMS matching a given filter

Compal options:

--compal-query-at-command="<AT command>"

send AT command to modem, and receive AT response

Intel AT Tunnel options:

--intel-at-tunnel-set-at-command="<AT command>"

send AT command to modem, and receive AT response

Application Options:

-d, --device=[PATH]

Specify device path

-p, --device-open-proxy

Request to use the 'mbim-proxy' proxy

--device-open-ms-mbimex-v2

Request to enable Microsoft MBIMEx v2.0 support

--device-open-ms-mbimex-v3

Request to enable Microsoft MBIMEx v3.0 support

--no-open=[Transaction ID]

Do not explicitly open the MBIM device before running the command

--no-close

Do not close the MBIM device after running the command

--noop Don't run any command

-v, --verbose

Run action with verbose logs, including the debug ones

--verbose-full

Run action with verbose logs, including the debug ones and personal info

--silent

Run action with no logs; not even the error/warning ones

--printable=[(Data)]

Get the printable info of the given hex encoded MBIM message

-V, --version

Print version

COPYRIGHT

Copyright ? 2013-2023 Aleksander Morgado License GPLv2+: GNU GPL version 2 or later

<<http://gnu.org/licenses/gpl-2.0.html>>

This is free software: you are free to change and redistribute it. There is NO WARRANTY, to the extent permitted by law.

SEE ALSO

The full documentation for mbimcli is maintained as a Texinfo manual. If the info and mbim? cli programs are properly installed at your site, the command

info mbimcli

should give you access to the complete manual.

mbimcli 1.32.0

December 2025

MBIMCLI(1)