



**Full credit is given to the above companies including the Operating System (OS) that this PDF file was generated!**

### ***Rocky Enterprise Linux 9.2 Manual Pages on command 'sg\_emc\_trespass.8'***

**\$ man sg\_emc\_trespass.8**

SG\_EMCA\_TRESPASS(8) SG3\_UTILS SG\_EMCA\_TRESPASS(8)

#### **NAME**

sg\_emc\_trespass - change ownership of SCSI LUN from another Service-Processor to this one

#### **SYNOPSIS**

sg\_emc\_trespass [-d] [-hr] [-s] [-V] DEVICE

#### **DESCRIPTION**

sg\_emc\_trespass sends an EMC-specific Trespass Command to the DEVICE with the selected op?

tions. This Mode Select changes the ownership of the LUN of the device from another Ser?  
vice-Processor to the one the command was received on.

#### **OPTIONS**

Arguments to long options are mandatory for short options as well.

**-d** outputs some extra debug information associated with executing this command

**-hr** Sets the 'Honor Reservation' bit in the command. If set, the trespass will only succeed to change the ownership from the Peer SP if the Peer SP does not have an outstanding SCSI reservation for the LUN. By default, the reservation state will be ignored.

**-s** Send the short version of the trespass command instead of the long version. The short version is supported on the EMC FC5300, FC4500 and FC4700. The long version (default) is supported on the CLARiiON CX and AX family arrays.

**-V** print out version string then exit.

In the 2.4 series of Linux kernels the DEVICE must be a SCSI generic (sg) device. In the 2.6 series block devices (e.g. SCSI disks and DVD drives) can also be specified. For example "sg\_start 0 /dev/sda" will work in the 2.6 series kernels.

## EXIT STATUS

The exit status of `sg_emc_trespass` is 0 when it is successful. Otherwise see the `sg3_utils(8)` man page.

## AUTHOR

Written by Lars Marowsky-Bree, based on `sg_start`.

## REPORTING BUGS

Report bugs to <`dgilbert` at `interlog dot com`>.

## COPYRIGHT

Copyright ? 2004-2012 Lars Marowsky-Bree, Douglas Gilbert.

This software is distributed under the GPL version 2. There is NO warranty; not even for  
MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

`sg3_utils-1.35`

December 2012

`SG_EMU_TRESPASS(8)`