



Red Hat Enterprise Linux Release 9.2 Manual Pages on 'nvme-subsystem-reset.1' command

\$ man nvme-subsystem-reset.1

NVME-SUBSYSTEM-RES(1) NVMe Manual NVME-SUBSYSTEM-RES(1)

NAME

nvme-subsystem-reset - Reset the nvme subsystem.

SYNOPSIS

nvme subsystem-reset <device>

DESCRIPTION

Requests NVMe subsystem reset. The <device> param is mandatory and must be an NVMe character device (ex: /dev/nvme0).

OPTIONS

None

EXAMPLES

? Resets the subsystem.

```
# nvme subsystem-reset /dev/nvme0
```

NVME

Part of the nvme-user suite

NVMe 06/23/2023 NVME-SUBSYSTEM-RES(1)