



## ***Rocky Enterprise Linux 9.2 Manual Pages on command 'nvme-wdc-clear-pcie-correctable-errors.1'***

***\$ man nvme-wdc-clear-pcie-correctable-errors.1***

NVME-WDC-CLEAR-PC(1)      NVMe Manual      NVME-WDC-CLEAR-PC(1)

### NAME

nvme-wdc-clear-pcie-correctable-errors - Clears the pcie correctable errors field returned in the smart-log-add command.

### SYNOPSIS

nvme wdc clear-pcie-correctable-errors <device>

### DESCRIPTION

For the NVMe device given, sends the wdc vendor unique clear pcie correctable errors command.

The <device> parameter is mandatory and may be either the NVMe character device (ex: /dev/nvme0), or a namespace block device (ex: /dev/nvme0n1).

This will only work on WDC devices supporting this feature. Results for any other device are undefined.

### OPTIONS

None

### EXAMPLES

? Clears the PCIe Correctable Error Count field returned in the

smart-log-add command:

```
# nvme wdc clear-pcie-correctable-errors /dev/nvme0
```

## NVME

Part of the nvme-user suite

NVMe	06/23/2023	NVME-WDC-CLEAR-PC(1)
------	------------	----------------------