

Full credit is given to the above companies including the OS that this PDF file was generated!

Rocky Enterprise Linux 9.2 Manual Pages on command 'sane-dmc.5'

\$ man sane-dmc.5

sane-dmc(5)

SANE Scanner Access Now Easy

sane-dmc(5)

NAME

sane-dmc - SANE backend for the Polaroid Digital Microscope Camera

DESCRIPTION

The sane-dmc library implements a SANE (Scanner Access Now Easy) back? end that provides access to the Polaroid Digital Microscope Camera.

DEVICE NAMES

This backend expects device names of the form:

special

Where special is the UNIX path-name for the special device that corre? sponds to the scanner. The special device name must be a generic SCSI device or a symlink to such a device. Under Linux, such a device name could be /dev/sga or /dev/sge, for example.

IMAGING MODES

The Polaroid DMC supports a number of imaging modes. This driver sup? ports five of the imaging modes:

Full Frame

This mode corresponds to the 801-by-600 pixel full-color full-frame image.

Viewfinder

This mode corresponds to the 270-by-201 pixel grey-scale viewfinder image. This image is acquired very quickly.

Raw This mode corresponds to the 1599-by-600 pixel "raw" image from the CCD. It is grey-scale, with pixels alternating horizontally between red, green and blue stripes. The pixels are twice as high as they are wide, so the image is distorted.

Thumbnail

This mode corresponds to the 80-by-60 pixel full-color thumbnail image.

Super Resolution

This image is a 1599-by-1200 pixel full-color image constructed by filtering and interpolating the "raw" image. The filtering and interpolation is done in software, so this mode is very slow. Also, this mode places restrictions on how the image is read which means that the "preview" mode of xscanimage does not work in Super Resolution mode. (xcam(1) and the non-preview modes of scanimage(1) and xscanimage(1) work fine, however.)

OTHER SETTINGS

ASA Setting Page 2/5

This setting adjusts the camera's sensitivity. You can choose one of 25, 50, or 100 "equivalent" ASA.

Shutter Speed

You can select a shutter speed from 8 to 1000 milliseconds. The shutter speed is quantized in units of 32 microseconds.

White Balance

You can choose one of "Daylight", "Incandescent" or "Fluores? cent" white balances. This setting more-or-less corresponds to the "Color Temperature" settings on Polaroid's Windows and Mac software.

CONFIGURATION

The contents of the dmc.conf file is a list of device names that corre?

spond to DMC scanners. Empty lines and lines starting with a hash mark

(#) are ignored. A sample configuration file is shown below:

/dev/scanner

this is a comment

/dev/sge

FILES

/etc/sane.d/dmc.conf

The backend configuration file (see also description of SANE_CONFIG_DIR below).

/usr/lib64/sane/libsane-dmc.a

The static library implementing this backend.

/usr/lib64/sane/libsane-dmc.so

The shared library implementing this backend (present on systems that support dynamic loading).

ENVIRONMENT

SANE_CONFIG_DIR

This environment variable specifies the list of directories that may contain the configuration file. Under UNIX, the directories are separated by a colon (`:'), under OS/2, they are separated by a semi-colon (`;'). If this variable is not set, the config? uration file is searched in two default directories: first, the current working directory (".") and then in /etc/sane.d. If the value of the environment variable ends with the directory sepa? rator character, then the default directories are searched after the explicitly specified directories. For example, setting SANE_CONFIG_DIR to "/tmp/config:" would result in directories tmp/config, ., and /etc/sane.d being searched (in this order).

SANE_DEBUG_DMC

If the library was compiled with debug support enabled, this en? vironment variable controls the debug level for this backend.

E.g., a value of 128 requests all debug output to be printed.

Smaller levels reduce verbosity.

BUGS

In the "Full Frame" and "Raw" modes, images must be read in units of entire lines. The driver performs no buffering in these modes; if you ask sane_read to read a non-integral number of lines, it may read less than you ask for. If you ask sane_read to read less than a single line, it returns SANE STATUS INVAL.

In the "Super Resolution" mode, images must be read in units of two lines (3198 pixels or 9594 bytes). If you try to read less than two lines, you get SANE_STATUS_INVAL. The Super Resolution mode is very slow.

In the "Viewfinder" and "Thumbnail" modes, the entire image must be read in one SCSI transfer. In this case, the driver performs buffering and you can read the image in as small an increment as you like.

SEE ALSO

sane(7), sane-scsi(5)

AUTHOR

David F. Skoll

The backend is derived from sane-hp(5) by David Mosberger

13 Jul 2008

sane-dmc(5)