



Linux Ubuntu 26.04 Manual Pages on command 'hp-colorcal.1'

\$ man hp-colorcal.1

hp-colorcal(1) User Manuals hp-colorcal(1)

NAME0p-colorcal - Printer Cartridge Color Calibration Utility

DESCRIPTION

Perform color calibration on HPLIP supported inkjet printers. (Note: Not all printers require the use of this utility).

SYNOPSIS

hp-colorcal [DEVICE_URI|PRINTER_NAME] [MODE] [OPTIONS]

PRINTER|DEVICE-URI

To specify a device-URI:

-d<device-uri> or --device=<device-uri>

To specify a CUPS printer:

-p<printer> or --printer=<printer>

MODE

Run in interactive mode:

-i or --interactive

OPTIONS

Set the logging level:

-l<level> or --logging=<level> <level>: none, info*, error, warn, debug (*default)

Run in debug mode:

-g (same as option: -ldebug)

This help information:

-h or --help

SEE ALSO

hp-align hp-clean hp-linefeedcal hp-pqdiag

AUTHOR

HPLIP (HP Linux Imaging and Printing) is an HP developed solution for printing, scanning, and faxing with HP inkjet and laser based printers in Linux.

REPORTING BUGS

The HPLIP Launchpad.net site <https://launchpad.net/hplip> is available to get help, report bugs, make suggestions, discuss the HPLIP project or otherwise contact the HPLIP Team.

COPYRIGHT

Copyright (c) 2001-18 HP Development Company, L.P.

This software comes with ABSOLUTELY NO WARRANTY. This is free software, and you are welcome to distribute it under certain conditions. See COPYING file for more details.

Linux

3.0

hp-colorcal(1)