

Full credit is given to the above companies including the OS that this PDF file was generated!

# Rocky Enterprise Linux 9.2 Manual Pages on command 'Ishw.1'

### \$ man Ishw.1

LSHW(1)

LSHW(1)

NAME

Ishw - list hardware

### **SYNOPSIS**

```
lshw [-version ]
lshw [-help ]
lshw [-X]
lshw [ [-html ] [-short ] [-xml ] [-json ] [-businfo ] ] [
-dump filename ] [-class class... ] [-disable test... ] [-enable test... ] [-sanitize ] [-numeric ] [-quiet ] [-notime ]
```

## **DESCRIPTION**

Ishw is a small tool to extract detailed information on the hardware configuration of the machine. It can report exact memory configuration, firmware version, mainboard configuration, CPU version and speed, cache configuration, bus speed, etc. on DMI-capable x86 or IA-64 systems and on some PowerPC machines (PowerMac G4 is known to work).

It currently supports DMI (x86 and IA-64 only), OpenFirmware device tree (PowerPC only), PCI/AGP, CPUID (x86), IDE/ATA/ATAPI, PCMCIA (only

tested on x86), SCSI and USB.

### -version

Displays the version of Ishw and exits.

- -help Displays the available command line options and quits.
- -X Launch the X11 GUI (if available).
- -html Outputs the device tree as an HTML page.
- -xml Outputs the device tree as an XML tree.
- -json Outputs the device tree as a JSON object (JavaScript Object No? tation).
- -short Outputs the device tree showing hardware paths, very much like the output of HP-UX's ioscan.

### -businfo

Outputs the device list showing bus information, detailing SCSI, USB, IDE and PCI addresses.

### -dump filename

Display output and dump collected information into a file (SQLite database).

### -class class

Only show the given class of hardware. class can be found using lshw -short or lshw -businfo.

### -C class

Alias for -class class.

### -enable test

### -disable test

Enables or disables a test. test can be dmi (for DMI/SMBIOS ex? tensions), device-tree (for OpenFirmware device tree), spd (for memory Serial Presence Detect), memory (for memory-size guessing heuristics), cpuinfo (for kernel-reported CPU detection), cpuid (for CPU detection), pci (for PCI/AGP access), isapnp (for ISA PnP extensions), pcmcia (for PCMCIA/PCCARD), ide (for IDE/AT? API), usb (for USB devices),scsi (for SCSI) or network (for net? work interfaces detection).

```
-sanitize
        Remove potentially sensitive information from output (IP ad?
        dresses, serial numbers, etc.).
    -numeric
        Also display numeric IDs (for PCI and USB devices).
    -notime
        Exclude volatile attributes (timestamps) from output.
BUGS
    Ishw currently does not detect Firewire(IEEE1394) devices.
    Not all architectures supported by GNU/Linux are fully supported (e.g.
    CPU detection).
    "Virtual" SCSI interfaces used for SCSI emulation over IDE are not re?
    ported correctly yet.
NOTES
    Ishw must be run as super user or it will only report partial informa?
    tion.
FILES
    /usr/local/share/pci.ids
    /usr/share/pci.ids
    /etc/pci.ids
    /usr/share/hwdata/pci.ids
        A list of all known PCI ID's (vendors, devices, classes and sub?
        classes). If compiled with zlib support, Ishw will look for
        pci.ids.gz first, then for pci.ids.
    /proc/bus/pci/*
        Used to access the configuration of installed PCI buses and de?
        vices.
    /proc/ide/*
        Used to access the configuration of installed IDE buses and de?
        vices.
    /proc/scsi/*, /dev/sg*
        Used to access the configuration of installed SCSI devices.
```

/dev/cpu/\*/cpuid Page 3/4

Used on x86 platforms to access CPU-specific configuration. /proc/device-tree/\* Used on PowerPC platforms to access OpenFirmware configuration. /proc/bus/usb/\* Used to access the configuration of installed USB buses and de? vices. /sys/\* Used on 2.6 kernels to access hardware/driver configuration in? formation. **EXAMPLES** Ishw -short Lists hardware in a compact format. Ishw -class disk -class storage Lists all disks and storage controllers in the system. Ishw -html -class network Lists all network interfaces in HTML. Ishw -disable dmi Don't use DMI to detect hardware. SEE ALSO /proc/\*, linuxinfo(1), lspci(8), lsusb(8) **COPYING** Ishw is distributed under the GNU GENERAL PUBLIC LICENSE (GPL) version 2. **AUTHOR** Ishw is maintained by Lyonel Vincent <lyonel@ezix.org>. OTHER INFO The webpage for Ishw is at <URL:http://lshw.ezix.org/>

15 October 2020

LSHW(1)

\$Rev\$