

Full credit is given to the above companies including the OS that this PDF file was generated!

# Rocky Enterprise Linux 9.2 Manual Pages on command 'ledctl.8'

#### \$ man ledctl.8

ledctl(8) Intel(R) Enclosure LED Control Application ledctl(8)

NAME

ledctl - Intel(R) LED control application for a storage enclosures.

### **SYNOPSIS**

ledctl [OPTIONS] pattern\_name=list\_of\_devices ...

### **DESCRIPTION**

The ledctl is an user space application designed to control LEDs associated with each slot in an enclosure or a drive bay. The LEDs of devices listed in list\_of\_devices are set to the given pattern pattern\_name and all other LEDs are turned off. User must have root privileges to use this application.

There are two types of systems: 2-LEDs systems (Activity LED, Status

LED) and 3-LEDs systems (Activity LED, Locate LED, Fail LED).

The ledctl application supports LED management of the SAS/SATA and PCIe storages.

Supported protocols/methods for LED management are:

- ? SES-2 and SMP for SAS devices,
- ? LED messages over SGPIO for SATA,

? VMD and NPEM for PCIe.

SAF-TE protocol is not supported.

For SAS/SATA storages supporting controllers may transmit LED management information to the backplane controllers via the SGPIO interface. The SGPIO bus carries bit patterns, which translate into LED blink patterns in accordance with the International Blinking Pattern Interpretation (IBPI) of SFF-8489 specification for SGPIO. Please note some enclosures do not stick close to the SFF-8489 specification. It might happen that the enclosure processor will accept the IBPI pattern but it will blink LEDs not according to SFF-8489 specification or it has a limited number of patterns supported.

The ledctl application has been verified to work with Intel(R) storage controllers (i.e. Intel(R) AHCI controller and Intel(R) SAS controller). The application might work with storage controllers of other vendors (especially SCSI/SAS controllers). However, storage controllers of other vendors have not been tested.

The ledmon application has the highest priority when accessing LEDs. It means that some patterns set by ledctl may have no effect if ledmon is running (except Locate pattern).

The ledctl application is a part of Intel(R) Enclosure LED Utilities.

The ledctl utilizes the following documents as references:

- ? SGPIO (Serial GPIO) SFF-8485
- ? IBPI (International Blinking Pattern Interpretation) SFF-8489
- ? LED Enclosure management messages AHCI specification rev 1.3, section 12.2.1.
- ? SAS (Serial Attached SCSI) T10/1760-D
- ? SES-2 (SCSI Enclosure Services-2) T10/1559-D
- ? SMP (Serial Management Protocol) T10/1760-D
- ? NPEM (Native PCIe Enclosure Management) PCIe base specification rev 4.0
- ? VMD (Intel(R) Volume Management Device) Intel(R) VROC (VMD NVMe RAID) Quick

Pattern Names The ledctl application accepts the following names for pattern\_name argument according to SFF-8489 specification. locate Turns Locate LED associated with the given device(s) on. locate\_off Turns only Locate LED off. normal Turns Status LED, Failure LED and Locate LED off. off Turns only Status LED and Failure LED off. ica or degraded Visualizes "In a Critical Array" pattern. rebuild Visualizes "Rebuild" pattern. ifa or failed\_array Visualizes "In a Failed Array" pattern. hotspare Visualizes "Hotspare" pattern. Visualizes "Predicted Failure Analysis" pattern. failure or disk\_failed Visualizes "Failure" pattern. ses\_abort SES-2 R/R ABORD ses\_rebuild SES-2 REBUILD/REMAP ses\_ifa SES-2 IN FAILED ARRAY ses\_ica SES-2 IN CRIT ARRAY ses\_cons\_check SES-2 CONS CHECK ses\_hotspare SES-2 HOT SPARE ses\_rsvd\_dev

SES-2 RSVD DEVICE

ses\_ok SES-2 OK

ses\_ident

Page 3/7 **SES-2 IDENT** 

```
ses rm SES-2 REMOVE
  ses_insert
      SES-2 INSERT
  ses_missing
       SES-2 MISSING
  ses_dnr SES-2 DO NOT REMOVE
  ses_active
       SES-2 ACTIVE
  ses enable bb
       SES-2 ENABLE BYP B
  ses_enable_ba
       SES-2 ENABLE BYP A
  ses_devoff
      SES-2 DEVICE OFF
  ses_fault
      SES-2 FAULT
  ses_prdfail
       SES-2 PRDFAIL
Patterns Translation
  When non SES-2 pattern is send to device in enclosure automatic
  translation is being done.
  locate locate is translated to ses_ident
  locate_off
      locate_off is translated to ~ses_ident
  normal or off
       normal or off is translated to ses_ok
  ica or degraded
       ica or degraded is translated to ses_ica
  rebuild rebuild is translated to ses_rebuild
  ifa or failed_array
      ifa or failed_array is translated to ses_ifa
  hotspare
```

hotspare is translated to ses\_hotspare

pfa pfa is translated to ses\_prdfail

failure or disk failed

failure or disk\_failed is translated to ses\_fault

#### List of Devices

The application accepts a list of devices in two formats. The first format is a list with comma separated elements. The second format is a list in curly braces and elements are separated by space. See examples section below for details.

A device is a path to file in /dev directory or in /sys/block directory.

The LEDs of devices listed in list\_of\_devices are set to the given pattern pattern\_name and all other LEDs, on all devices, are turned off (unless --listed-only option is given).

## **OPTIONS**

-l or --log=path

Sets a path to local log file. If this option is specified the global log file /var/log/ledctl.log is not used.

-h or --help

Prints this text out and exits.

-v or --version

Displays version of ledctl and information about the license and exits.

-L or --list-controllers

Prints information (system path and type) of all controllers detected by ledmon and exits.

-x or --listed-only

With this option ledctl will change state only on devices listed in CLI. The rest of devices will not be touched.

--quiet or --error or --warning or --info or --debug or --all Verbose level - 'quiet' means no logging at all and 'all' means to log everything. The levels are given in order. If user specifies more then one verbose option the last option comes into effect. The default level is 'warning'. Verbose level also can be set by --log-level=level.

## **FILES**

/var/log/ledctl.log

Global log file, used by all instances of ledctl application.

To force logging to user defined file use -I option switch.

## **EXAMPLES**

The following example illustrates how to set locate on a single block device. Note that all remaining LEDs, on all devices, will be turned off.

ledctl locate=/dev/sda

The following example illustrates how to set locate\_off on a single block device.

ledctl --listed-only locate\_off=/dev/sda

The following example illustrates how to set off on the given devices.

It uses second format of device list.

ledctl --listed-only off={ /dev/sda /dev/sdb }

The following example illustrates how to set locate and rebuild on different devices at the same time. It uses the second format of device list.

ledctl --listed-only locate={ /dev/sdb } rebuild={ /sys/block/sdc }

The following example illustrates how to locate on three block devices.

It uses the first format of device list.

ledctl --listed-only locate=/dev/sda,/dev/sdb,/dev/sdc

The following example illustrates how to set locate and rebuild on different devices at the same time. It uses the first format of device list.

ledctl --listed-only locate=/dev/sdb rebuild=/sys/block/sdc

The following example illustrates how to set locate and rebuild on different devices at the same time. It uses the both formats of device

list.

ledctl --listed-only locate={ /dev/sdb } rebuild=/sys/block/sdc

## LICENSE

This program is distributed under the terms of the GNU General Public License as published by the Free Software Foundation. See the built-in help for details on the License and the lack of warranty.

# SEE ALSO

ledmon(8), ledmon.conf(5)

## **AUTHOR**

This manual page was written by Artur Wojcik <artur.wojcik@intel.com>.

It may be used by others.

LEDCTL Version 0.96

May 2022

ledctl(8)